

**MANUALE OPERATIVO MOD. CANNELLO NEPTUNE
CANNELLI CONFORMI ALLA NORMA ISO EN9012 A GAS PROPANO O BUTANO
PER LA SALDATURA DELLE MEMBRANE**

DATI TECNICI:

Campana	Braccio	Peso (g)	Kcal/h	Kw	Kj/h	Pressione Utilizzo bar	Consumo Max Kg/h
50	180/350	600/625	53550	62,27	224162	2 – 4	4,5
60	180/350	670/695	64260	74,72	268995	2 – 4	5,4

ISTRUZIONI PER UN CORRETTO USO

Utilizzare in ambiente esterno

Assicurarsi di aver collegato correttamente il tubo flessibile connettendolo rigorosamente in ordine prima al cannello poi alla bombola del gas.

Accensione:

- 1- Chiudere i rubinetti del cannello;
- 2- Aprire il rubinetto della bombola del gas;
- 3- Regolare la pressione del gas con l'apposito registro posto sul regolatore.
- 4- Premere il pulsante sulla valvola (se fornita);
- 5- Aprire sufficientemente il pomello nero del cannello;
- 6- Eseguire l'accensione, regolare il minimo della fiamma desiderata dal pomello in ottone;
- 7- Usare la leva per ottenere il massimo rendimento.
(il pomello nero regola il flusso gas della leva.)
- 8- In caso di vento o situazioni atmosferiche avverse, incrementare la fiamma di minimo ruotando in senso antiorario il pomello piccolo in ottone

Spegnimento:

- 1- Chiudere il rubinetto della bombola del gas;
- 2- Consumare tutto il gas contenuto nel tubo di gomma;
- 3- Chiudere entrambi i registri di minimo del cannello;

Accessori di sicurezza:

- 1- Valvola applicata sul regolatore, che blocca il flusso del gas in caso di rottura del tubo di gomma o comunque nel verificarsi di uno sbalzo di pressione dovuto ad altre cause;
- 2- Piedistallo, utilizzabile nei momenti operativi, che permette di appoggiare a terra il cannello con la fiamma rivolta verso l'alto (in dotazione).

NORME DI SICUREZZA

- * Operare sempre con un estintore a polvere nelle vicinanze;
- * Non puntare la fiamma su materiali infiammabili;
- * Mai appoggiare la campana calda sul manto bituminoso;
- * Sostituire la guarnizione (gomma NBR) tra regolatore e bombola gas ad ogni cambio della medesima;
- * Mantenere la bombola del gas alla massima distanza;
- * Non scaldare la bombola del gas con la fiamma;
- * Controllare sempre lo stato di integrità del tubo di gomma e non usarlo come fune per sollevare altri materiali;
- * Non lasciare il cannello acceso in caso di abbandono, anche momentaneo, del posto di lavoro;
- * Non manomettere qualsiasi parte dell'attrezzatura (cannello, regolatore di gas, tubo di gomma) poiché è a cura del produttore sottoporre a collaudo i materiali a fine produzione, per eventuali riparazioni rivolgersi a personale autorizzato;
- * Utilizzare i dispositivi di protezione individuali segnalati dal RSPP, (D.Lgs. 81/08);
- * Per controllare una probabile perdita di gas nell'attrezzatura usare una miscela di acqua e sapone;
- * Usare tubi di gomma omologati o conformi per gas ISO3821 (ex EN559) di colore arancio, utilizzando apposite fascette per serrare i raccordi di cannello e regolatore.

**OPERATIVE MANUAL MOD. NEPTUNE
GAS (PROPANE OR BUTANE) TORCHES IN COMPLIANCE WITH REGULATIONS ISO EN 9012
FOR BITUMEN MEMBRANE SEALINGS**

TECHNICAL DATA:

Burner Head	Extension	Weight (g)	Kcal/h	Kw	Kj/h	Working Pressure bar	Max Consumption Kg/h
50	180/350	600/625	53550	62,27	2241 62	2 – 4	4,5
60	180/350	670/695	64260	74,72	268995	2 – 4	5,4

ISTRUCTIONS FOR A CORRECT USE

Use exclusively on the outside and in open air

Please make sure that the flexible hose has been correctly connected rigorously in order before to the welding torch and then to gas cylinder.

IGNITION:

- 1-Close both small tap and black knob clockwise
- 2-Open the main tap of the gas cylinder
- 3- Regulate gas pressure through the valve placed on the gas regulator (if provided). **It is recommended not to remove the nut on the throttle in order not to break the membrane with a consequent gas leak.**
- 4- Push button located on security valve (if supplied) until the hose is totally fulfilled with gas
- 5-Slightly open the black torch knob
- 6- Ignite the torch. Regulate the brass knob to obtain desired pilot flame.
- 7-Pull the lever to get maximum output (the black knob controls the lever gas flow)
- 8- In case of wind or inclement weather conditions, increase the pilot flame by turning anticlockwise the small brass knob.

TURN-OFF:

- 1-Close the main tap on the gas cylinder
- 2-Consume all the residual gas in the rubber hose
- 3-Close the torch taps and knobs.

SAFETY DEVICES:

- 1- An excess flow security valve is placed on the regulator for immediate stop of gas flow in case of rubber hose damage or sudden pressure change due to external causes
- 2- A torch stand is provided as STD equipment in order to lay the torch when in use. This allows the torch to rest in a upright position onto the floor.

SAFETY REGULATIONS

- *Always work with a dry powder fire extinguisher at hand
- *Do not ever apply the flame towards flammable material
- * Never lay hot burner head directly on the bituminous mantle
- *Whenever gas cylinder is changed, be sure to also change the gasket in NBR rubber between regulator and gas cylinder itself, where it is necessary.
- *Keep the gas cylinder at the maximum distance possible
- * It is severely forbidden to heat up the gas cylinder with any flame
- *Always check rubber hose is in perfect conditions and strictly avoid to use it as a rope to lift-up other materials
- *Do not ever leave the torch ignited unattended, even for a very short period of time.
- *Do not ever modify any part of the equipment (torch, gas regulator, rubber hose) as it is duty of the manufacturer to test all the material at the end of manufacturing process. In case of assistance, strictly contact authorized personnel only.
- *Wear approved personal protection devices during any long lasting or indoor work (according to each domestic regulations).
- *When checking the equipment for possible leaks, use soapy water
- *Exclusively use gas homologated rubber hoses or in compliance with each domestic rule and specific clamps to tighten torch and regulator connections.